

Window Cleaning Solution

Irradiated Solution for windows and hard surfaces



Contec’s Window Cleaning Solution is a specialized formula designed to remove cleanroom residues from glass. It contains 3% IPA, 0.2% ammonium hydroxide, and 2.9% surfactant in DI water, ensuring effective residue solubilization for easy removal. Irradiated for use in critical areas, the solution is equipped with a trigger spray or reclosable cap to evenly distribute the liquid, minimizing streaks.

For best results, use Contec’s Window Cleaning Solution with Contec’s Window Cleaning Squeegee. This combination creates a streak-free surface while effectively eliminating contamination and residue.



Features	Benefits
IPA, ammonium hydroxide and surfactant blend	<ul style="list-style-type: none"> • Unique combination solubilizes residues allowing them to be easily removed from surfaces
Low VOC's	<ul style="list-style-type: none"> • Low IPA level means little to no VOC's compared to 70% IPA
Trigger and recloseable cap	<ul style="list-style-type: none"> • Tailored to meet end-user preferences and SOP guidelines
Irradiated solution filtered through 0.2 micron	<ul style="list-style-type: none"> • Eliminates the need for in-house filtration • Prefiltered, packaged and irradiated for easy introduction into critical environments

Part No.	Description	Size	Packaging
SBT32WC	Window Cleaning Solution, Irradiated capped with a reclosable cap and spray trigger	32 oz (1 L)	12/case

Product Information	
Appearance	Clear to pale yellow liquid
Odor	Characteristic
Water Quality	Meets the requirements of USP grade deionized water
% IPA Contents	3.8%
Specific Gravity (20C)	1.00%
Packaging materials	Outer bags (OB1, OB2), low density polyethylene (LDPE)  Case (CS), corrugated fiberboard (PAP) 
Environment	ISO 3-8 Grade A/D
Shelf life	2 years

Recycle Symbols

- PET 
- HDPE 
- LDPE 
- PP 
- PAP 

VOC Content	VOC (LBS/CS)	VOC (LBS/Bottle)
SBT32WC	0.75	0.063