

Multi-Bucket Systems

Multi-Bucket Systems for use with Contec’s string mops

Contec’s Multi-Bucket System offers maximum flexibility and can be fitted with two or three buckets, in either stainless steel or polypropylene. An extendable frame pulls out of the front of the cart to accommodate an additional bucket. Each cart is fitted with quiet, easy to move casters that lock in place when needed. The utility handle allows for transportation of additional cleaning supplies. One mop holder with mop brace and handle clasps on either side of the cart keep the handles in position and allow for convenient mop storage during transport.


This multi-bucket system offers the ability to customize the system with whichever wringer best coincides with the mopping system. The system is compatible with stainless steel downpress wringer to accommodate string mops.

Autoclavable at 121° C for 30 minutes.



Features	Benefits
Specified handle accommodates string mop wringer	<ul style="list-style-type: none"> • Allows the system to be used with Contec’s Edgeless Mops
Removable handle	<ul style="list-style-type: none"> • Makes for easier autoclaving and storage
Extendable cart for optional 3rd bucket	<ul style="list-style-type: none"> • Cart extends to transform cart to three bucket system if needed for facility protocol
Improved castors and connections	<ul style="list-style-type: none"> • Significantly reduces noise during use • More durable attachments with less “rattle”

Part No.	Description	Size	Packaging
2707U2SS	Stainless Steel Multi-Bucket System Two 7 gallon (27 L) stainless steel buckets with utility handle	7 gallon (27 L)	1/case
2650U2PS	Polypropylene Multi-Bucket System Two 6.5 gallon (25 L) polypropylene buckets with utility handle and drip cap	6.5 gallon (25 L)	1/case
Wringers			
6037	Stainless Steel Downpress Wringer for string mops	-	1/case
Accessories			
2617	Stainless Steel Bucket Replacement bucket	7 gallon (27 L)	1/case
UBKT0001	Blue Polypropylene Bucket Replacement bucket	6.5 gallon (25 L)	1/case
UBKT0002	Red Polypropylene Bucket Replacement bucket	6.5 gallon (25 L)	1/case
UBKT0003	Gray Polypropylene Bucket Replacement bucket	6.5 gallon (25 L)	1/case
6026	Replacement Casters	-	

Product Information	
Materials of construction	Stainless Steel Type 304
Cart	Stainless Steel Type 304
Handle Clips	Stainless Steel Type 304
Buckets	Polypropylene copolymer/stainless steel, type 316, deep drawn
Packaging materials	Case (CS), corrugated fiberboard (PAP) 
Dimensions	35" x 27" x 41" (89 x 61 x 104 cm)
Wringers (sold separately)	6037 – Stainless Steel downpress wringer (for Edgeless® Mop)

Recycle Symbols

- PET 
- HDPE 
- LDPE 
- PP 
- PAP 

Notes
 a) The data shown are typical values and should not be used as product specifications.
 b) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
 c) Comparison testing of Contec products against similar competitive or incumbent products may be conducted upon special request. Please contact a Contec Sales Representative for more information.