

# Window Cleaning Squeegee

## Autoclavable squeegee for cleanrooms

Contec's Squeegee is an easy-to-use tool that cleans windows and removes residues. The squeegee is made of stainless steel with a replaceable rubber blade. The tool is lightweight and compatible with QuickConnect™ handles so it can be used on tall, hard to reach windows. The press-down handle clip allows for easy installation with a secure hold preventing the rubber blade from moving during use. The screw-free channel allows blades to be replaced easily when needed. The ergonomic rubber grip fits nicely in hand and doesn't slip with disinfectants making it easy to use for cleaning windows and other hard surfaces.


The Squeegee is compatible with common cleanroom cleaners and disinfectants. Ideal for use with Contec's Window Cleaning Solution to solubilize residues that can then be easily removed with the Squeegee.

The Squeegee is fully autoclavable at 121° C for 30 minutes making it ideal for use in all grades of cleanrooms.



Features	Benefits
Lightweight, stainless-steel tool and rubber grip	<ul style="list-style-type: none"> <li>• Rubber grip prevents tool from slipping when used with disinfectants</li> <li>• Lightweight to clean tall windows and hard to reach areas</li> <li>• Maneuvers easily to use vertically and horizontally</li> </ul>
Compatibility	<ul style="list-style-type: none"> <li>• Compatible with all Contec's QuickConnect handles making windows easier to reach.</li> <li>• All components of the squeegee are compatible with common cleanroom cleaners and disinfectants</li> </ul>
Press Down Handle Clip	<ul style="list-style-type: none"> <li>• Allows for easy installation preventing the rubber blade from moving during use</li> </ul>
Screw-free channel	<ul style="list-style-type: none"> <li>• Blades to be replaced quickly and easily saving time</li> </ul>
Autoclavable	<ul style="list-style-type: none"> <li>• Squeegee can be autoclaved at 121° C for 30 minutes</li> <li>• Ideal for use in all areas of the cleanroom</li> </ul>

Part No.	Description	Size	Packaging
WCSQ0018	Window Cleaning Squeegee One stainless steel squeegee handle with adaptor, channel with blade installed, two blade replacements	18" (46 cm)	1/case
6084	Replacement QuickConnect Press-Fit Adaptor Adaptor for use with Window Cleaning Squeegee	-	1/case
WCSQB018	Window Cleaning Squeegee Replacement Blades	-	6/case

Product Information	
Materials of construction	Squeegee Hardware: 304 Stainless Steel, Rubber Handle Grip Squeegee Blade: Rubber Squeegee Adaptor: Stainless Steel and POM
Packaging materials	Case (CS), corrugated fiberboard (PAP) 
Dimensions	18" (46 cm)
Autoclavability	121° C for 30 minutes
Compatible Handles	CFH18, CFH32, 2642, 2645



WCSQ0018



6084

Recycle Symbols

