

PROSAT® Presaturated Wipes

Meltblown polypropylene wipes

Contec's PROSAT® Presaturated Wipes are made using meltblown polypropylene (MBPP) fabric and various blends of IPA and DI water. Meltblown polypropylene is exceptionally clean, free from additives of any kind and has a very low concentration of sodium. An excellent choice for general surface cleaning where fast drying times are desired, PROSAT® wipes are low in non-volatile residues as well as particles and fibers. The use of presaturated wipes provides maximum process control, reduces VOC emissions and solvent use up to 35% compared to spraying.



Features	Benefits
Convenient packaging	<ul style="list-style-type: none"> • Eliminates in-plant mixing
Solvent saturation levels and blends are consistent	<ul style="list-style-type: none"> • Eliminating operator error
Eliminates cross contamination	<ul style="list-style-type: none"> • A clean wipe is ready for each task
More accurate solvent usage	<ul style="list-style-type: none"> • VOC environmental reporting is easier and more reliable
Fabric meets specifications for critical applications	<ul style="list-style-type: none"> • Eliminates quality variabilities seen in many “rag” products
Safer	<ul style="list-style-type: none"> • Flammability hazards and airborne exposure levels are reduced
Performance	<ul style="list-style-type: none"> • Provide more accurate costs associated with solvent hand wiping applications

Part no.	Description	Size	Packaging
PS-850	PROSAT Meltblown Polypropylene Wipes Presaturated with 70% IPA/30% DI water	8" x 8" (203 x 203 mm)	50/bag; 50 bags/case
PS-911	PROSAT Meltblown Polypropylene Wipes Presaturated with 70% IPA/30% DI water	9" x 11" (230 x 280 mm)	30/bag; 50 bags/case
PS-919	PROSAT Meltblown Polypropylene Wipes Presaturated with 91% IPA/9% DI water	9" x 11" (230 x 280 mm)	30/bag; 50 bags/case
PSPP0043	PROSAT Meltblown Polypropylene Wipes Presaturated with 70% IPA/30% DI water	9" x 11" (230 x 280 mm)	50/bag; 40 bags/case
PSPP0047	PROSAT Meltblown Polypropylene Wipes Presaturated with 91% IPA/9% DI water	9" x 11" (230 x 280 mm)	50/bag; 40 bags/case
PSPP0048	PROSAT Meltblown Polypropylene Wipes Presaturated with 85% IPA/15% DI water	9" x 11" (230 x 280 mm)	50/bag; 40 bags/case
PSP70002	PROSAT Meltblown Polypropylene Wipes Presaturated with 85% IPA/15% DI water, quarter folded	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PSP70004	PROSAT Meltblown Polypropylene Wipes Presaturated with 75% IPA/25% PM, quarter folded	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PSP70005	PROSAT Meltblown Polypropylene Wipes Presaturated with 50% IPA/50% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PSPP0035	PROSAT Meltblown Polypropylene Wipes Presaturated with 70% IPA/30% DI water, quarter folded	11" x 17" (280 x 432 mm)	50/bag; 12 bags/case
PS-PP-955IDI	PROSAT Meltblown Polypropylene Wipes Presaturated with 95% IPA/5% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PS-PP-8020	PROSAT Meltblown Polypropylene Wipes Presaturated with 80% IPA/20% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PS-PP-8515	PROSAT Meltblown Polypropylene Wipes Presaturated with 85% IPA/15% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
SMPP0007	PROSAT Meltblown Polypropylene Wipes Presaturated with 70% IPA/30% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
CSPP0001	PROSAT Meltblown Polypropylene Wipes) Presaturated with 70% IPA/30% DI water, quarter folded	16" x 17" (406 x 432 mm)	50/bag; 12 bags/case + 1 SATBOX
PS-LPP-7030	PROSAT Meltblown Polypropylene Wipes Presaturated with 70% IPA/30% DI water, quarter folded	16" x 17" (406 x 432 mm)	50/bag; 15 bags/case
PS-LPP-8515	PROSAT Meltblown Polypropylene Wipes Presaturated with 85% IPA/15% DI water	16" x 17" (406 x 432 mm)	50/bag; 15 bags/case
CSCN0002	SATBOX for 11" x 17" quarter folded wipes, labeled w/Blue SATWIPES® IPA label	9.6" x 6.25" x 3" (244 x 159 x 76 mm)	4/case
CSCN0005	SATBOX for 16" x 17" quarter folded wipes, unlabeled	9.6" x 9.25" x 3" (244 x 235 x 76 mm)	12/case

Product Information			
Material	100% polypropylene		
Construction	Meltblown polypropylene		
Part no.	PS-850, PS-911, PS-919, PSPP0043, PSPP0035, PS-PP-955IDI, PS-PP-8020, PS-PP-8515, CSPP0001, PS-LPP-7030, PS-LPP-8515	PSP70002, PSP70004, PSP70005, SMPP0007	
Attributes (units)	Typical Value*	Typical Value*	Test Method
Basis weight (g/m ²)	34	36	
Non-volatile residue, NVR			IEST-RP-CC004.2, Sec. 6.1.2
In deionized water (g/m ²)	0.054	0.018	
In isopropyl alcohol (g/m ²)	0.014	0.008	
Specific ions			IEST-RP-CC004.2, Sec. 6.2.2
Sodium (ppm)	0	0	
Chloride (ppm)	0	0	
Particles, readily releasable P ≥ 3.0µm (x10 ⁶ /m ²)	0.132	0.112	IEST-RP-CC004.2, Sec. 5.1
Fibers > 100µm (x10 ³ /m ²)	3.4	4.4	IEST-RP-CC004.2, Sec. 5.2

VOC Content	VOC (LBS/PCH)	VOC (LBS/CS)	VOC Content	VOC (LBS/PCH)	VOC (LBS/CS)
PS-850	0.43	21.73	PS-PP-8515	1.51	30.10
PS-911	0.37	18.44	SMPP0007	1.32	26.32
PS-919	0.42	21.23	CSPP0001	1.22	14.69
PSPP0043	0.67	26.92	PS-LPP-7030	1.71	25.64
PSPP0047	0.81	32.54	PS-LPP-8515	2.00	29.96
PSPP0048	0.78	31.26			
PSP70002	1.56	31.26			
PSP70004	1.81	36.16			
PSP70005	0.47	9.31			
PSPP0035	1.33	15.95			
PS-PP-955IDI	1.54	30.76			
PS-PP-8020	1.44	28.81			

*Notes
 a) The data shown are typical values and should not be used as product specifications.
 b) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
 c) Current and/or comparison data may be available. Please contact a Contec sales representative for details.