

TuffStuff™ Workstation Wipes

Cellulose/polyester cleaning wipes

TuffStuff™ Workstation wipes are made from hydroentangled cellulose/polyester fabric for durability and cleanliness. They contain no binders or adhesives and are considered low lint. They offer excellent absorption with good strength when wet or dry, can stand up to many cleaning tasks and are conveniently packaged in a lightweight and portable perfed dispenser bag. TuffStuff wipes are creped for softness and sorbency. Ideal for tough cleaning and maintenance tasks, TuffStuff Workstation wipes are excellent for cleaning up soil, oils, grime, solvents and lubricants as well as applying solvents and thinners.



Features	Benefits
Hydroentangled nonwoven fabric	<ul style="list-style-type: none"> • Strong and durable without the use of binders
Creped	<ul style="list-style-type: none"> • Easy to pull wipes from bag for quick cleaning
Perfed dispenser bag	<ul style="list-style-type: none"> • Lightweight and portable convenience
Versatile	<ul style="list-style-type: none"> • Cleans up oils, grime, solvents, soils and lubricants or use to apply solvents and thinners

Part No.	Description	Size	Packaging
TSWC0100IN	TuffStuff Workstation Wipes Creped Interleave	9" x 16" (230 x 430 mm)	100/bag; 9 bags/case

Product Information		
Material	54% Wood Pulp, 46% Polyester	
Construction	Nonwoven - creped	
Attributes (units)	Typical Value*	Test Method
Basis weight (g/m ²)	56	-
Sorbency in water		IEST-RP-CC004.3, Sec. 8.1
Intrinsic (mL/g)	4.8	
Extrinsic (mL/m ²)	277	
Sorptive rate (seconds)	<1	
Non-volatile residue (NVR)		IEST-RP-CC004.3, Sec. 7.1.2
In deionized water (g/m ²)	0.01	
In isopropyl alcohol (g/m ²)	0.01	

Notes

- a) The data shown are typical values and should not be used as product specifications.
- b) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- c) Comparison testing of Contec products against similar competitive or incumbent products may be conducted upon special request. Please contact a Contec Sales Representative for more information.