

# EasyCurve™ Mop

## Lightweight mop for ceilings, walls and floors

Contec’s EasyCurve™ Mop was designed specifically for critical and controlled environments, now available with a ribbed microfiber face giving users smooth and easy mopping for better particle pick up and contamination removal. The combination of the curved mop face and the pivoting connector results in effortless surface contact and outstanding maneuverability, making the EasyCurve an ideal cleaning tool for ceilings, walls and floors. Available in nonsterile and validated sterile versions.

All components of the EasyCurve Mop are autoclavable. For convenience, EasyCurve mop heads are available validated sterile.

### Applications

Designed for use in pharmaceutical and medical device manufacturing plants, and other similar critical or controlled environments, the EasyCurve is an outstanding all-surface mop for use on ceilings, walls and floors.



With its absorbent and drip-free polyurethane foam mop head, the EasyCurve mop is an ideal choice for cleaning ceilings, walls and floors.

Features	Benefits
Hydrophilic polyurethane foam mop head	<ul style="list-style-type: none"> <li>• Very absorbent and drip-free</li> <li>• Compatible with most common solutions, solvents and disinfectants</li> </ul>
Laminated fabric face	<ul style="list-style-type: none"> <li>• Clean and durable, for most surfaces</li> </ul>
Ribbed microfiber face	<ul style="list-style-type: none"> <li>• Better contaminant removal</li> </ul>
Disposable flat-form mop head	<ul style="list-style-type: none"> <li>• Economical and easy to install without tools</li> <li>• Will not pinch or tear gloves</li> </ul>
Lightweight mop head and handle	<ul style="list-style-type: none"> <li>• Weighs much less than roller-type and self-wringing mops</li> <li>• Significantly reduces operator fatigue</li> </ul>
All components are autoclavable	<ul style="list-style-type: none"> <li>• Ideal for a wide range of cleaning applications in the most critical sterile environments</li> </ul>
Curved, pivoting mop frame	<ul style="list-style-type: none"> <li>• Provides effortless contact with surfaces</li> <li>• Ensures complete and uniform contact with all surfaces</li> <li>• Ensures proper “lift and pull” cleaning technique</li> </ul>

Part no.	Description		Size	Packaging
EZMP0300	EasyCurve Mop Head Ribbed microfiber		14" x 4.25" x 0.75" (36 x 11 x 2 cm)	4/bag; 12 bags/case
EZMP0350	EasyCurve Sterile Mop Head Ribbed microfiber		14" x 4.25" x 0.75" (36 x 11 x 2 cm)	1/bag; 48 bags/case
2724	EasyCurve Mop Frame Stainless steel		14" x 4.25" (36 x 11 cm)	1/case
2725E	QuickConnect™ One Piece Handle Stainless steel, autoclavable		60" (152 cm)	1/case
2643	QuickConnect™ Telescopic Handle Anodized aluminum, autoclavable		50" - 92" (127 - 233.7 cm)	1/case
2645	QuickConnect Telescopic Handle Stainless steel, autoclavable		50" - 92" (127 - 233.7 cm)	1/case

Contec Healthcare offers many compatible mopping systems. Visit our website for details.